




User Manual




OVIA Xtreme

True Wireless Earbuds with Charging Metal Case

www.oviastrong.com

1 Item list



*Note: When you need to charge for the charging case, please rotate the charging case until the charging port is exposed.



Manual



Charging Cable



Silicone earcaps
3 pairs

Packing list: a pair of earbuds, charging box, Type-C charging cable
three pairs of silicone ear caps, instruction manual

2 Power on/off

Power on

Method 1: When the charging box has remaining power, the earbuds will automatically turn on when the headset is taken out of the charging box.

Method 2: Press and hold the touch area for 2 seconds in the off state, and the earbuds will turn on.

***The blue light flash three times and then turns off when powering on, and the voice prompts "Power on"**



Power off

Method 1: Putting the earbuds into the charging case, it will automatically shut down;

Method 2: When disconnected with the cell phone , the earbuds will turn off after 3 minutes or 4 seconds of long press on the touch area;

***Indicator status: The white light flash three times and then goes out**

***Voice prompt: When its going to shut down, the voice prompt "Power off"**



3 About connection

*The connection includes the pairing between the left and right earbuds, and the pairing between the earbuds and the cell phone.

Connection between left and right earbuds

The two earbuds can be paired automatically after power on;

Indicator light before pairing: blue light flash alternately;

After the connection is completed, the indicator light: the blue light flashes, and will have a voice prompt: "Ding Dang".

Connection with cell phone

·Keep the bluetooth connecting with the cell phone.

·After the earbuds are power on, search for the Bluetooth signal on the terminal device, select select the paring name "OVIA Xtreme", and then select Connect to connect to the terminal device.

After the connection is completed, the indicator light goes out and the voice prompts "Connected"

·After the earbuds successfully completes a connection with the terminal device, when it is used again, the earbuds will automatically find the terminal device that was successfully connected last time, and try to connect with it.

4 Multi-connection

First, use A device to connect, when successfully connected, then disconnect; then use B device to search the paring name and connect, then come back to A device to find the pairing name and connect;

5 Operation function

Basic functions



 Previous song

 Touch*3



 Next song

 Touch*3



 Play / Pause

 Touch*2

Volume control



 Turn up volume

 Touch*1



 Reduce volume

 Touch*1

Phone Mode



 Answer the phone

 Touch*1

 Hang up the phone

 Touch*2

 Reject the call

 Touch*2

Mode switch



ANC on
or
ANC off

 Press 1.5s



Transparency on
or
Transparency off

 Press 1.5s

Voice assistant



Enable voice
assistant

 Touch*4

Disable voice
assistant

 Touch*2

6 Charge

Earbud charging

When the charging box has remaining power, put it into the charging compartment and close the cover to charge automatically.

Charging box charging

Please use the charging cable that comes with "OVIA Xtreme" to charge the charging box.

7 Reset earbuds

Reset steps	Indicator light
Delete the corresponding connection record on the terminal device, turn on the earbuds, and ensure that no terminal device is connected.	/
Touch the touch area of the two earbuds continuously for 2 times;	The blue light and white light flash quickly for 2 seconds, then turn into blue light and flash quickly
Reconnect with the terminal device to use;	/

8 Indicator light

Charging case status	Indicator light
Charge	0-30% :red light,31%-60%: yellow light, 61%-99%: white light, 100%: light off
Low battery alert	When the battery is lower than 5%, the red light flashes 8 times in 4 seconds and then light off
Charging box temperature is too high reminder	The red light blinks three times every 3 seconds until the temperature returns to normal
Earbuds status	Indicator light
Power on	Blue light flash 3 times for 1 second
Power off	The white light flash 3 times for 2 seconds, then turns off
The earbuds is waiting to be paired with the phone	Blue light flash
Successfully paired with the phone	Blue light off
Call in	The blue light flashes 2 times every 3 seconds
Charge	white light is steady on
Finished charging	Light off
Low battery alert	The white light flashes 2 times every 30 seconds

9 Prompt sound

Earphone status	Prompt sound
Power on	Power on
Power off	Power off
Earbuds connection	Ding Dang
Waiting to connect with mobile phone	Pairing
Successfully connected with the phone	Connected
Volume Max	Maximum Volume
Volume Max/Volume Min	Du Du
ANC ON/ANC OFF	ANC ON/ANC
Transparency on/Transparency off	Transparency on/Transparency
End call/Reject call	/
Low battery reminder	Battery low

10 Precautions

Precautions

1. Try to use the minimum volume that meets the needs. Long-term high-volume use will cause permanent hearing damage.
2. Please keep the device and accessories out of the reach of children, and children should use the device under adult supervision.
3. Do not soak the device in water. Avoid using this product while swimming, diving, **diving**, showering.
4. Do not use this product in places with damp, dusty or close to magnetic fields, so as not to cause internal circuit failure.
5. Avoid storing the earbuds in an environment below -15°C or above 50°C .
6. Avoid charging the earbuds or charging case in an environment below 0°C .
7. Do not place the earbuds on windowsills, car dashboards and other places exposed to direct sunlight for a long time.
8. Do not disassemble, modify the device, or insert foreign objects into the device, as these may cause damage to the device.



Warning: Excessive force or frequent rotation of the inner shell of the charging case may cause irreversible damage to the charging case, please rotate it only when necessary. Man-made damage cannot get free after-sales service.

Warning: There is a limit device inside the rotating mechanism. Do not rotate the inner shell of the charging box with excessive force, otherwise it may cause irreversible damage.